



1. Carefully cut the packing bands.
2. Detach the plywood cover from the top of the carton.
3. You may need to use the plywood cover later, please place it properly to keep in a decent condition.
4. Unlock the buckles and remove the carton.



NOTE: After unboxing, please read the Quick Reference Guide and refer to the Packing List to check if all the accessories are fully equipped.