





Thank you for purchasing this Autel diagnostic tool. Manufactured to a high standard, our tool will, if used according to these instructions and properly maintained, give you years of trouble-free performance.





WARNING:

- Serious or fatal crushing injuries can occur from frame tip-over. To prevent this frame from tipping over it must be secured to the ground during the assembly.
- Improper assembly of the calibration frame may result in permanent damage to the frame and may render it inoperable and/or unsafe.

Parts List


Crossbar 060005	1pc	Bolt (M5x10) 060019	4pcs
			

NOTE: Please find the below parts in the Calibration Frame package.

Sliding Laser Plate 060031	1pc	Hex L-wrench (4mm) 060032	1pc
			

Assemble the Crossbar

1



- Take out the Crossbar and the Sliding Laser Plate from the package cartons respectively.
- Attach the Crossbar Sliding Plate to the center of the crossbar, insert bolts (M5x10) on the side view and tighten them with the hex L – wrench (4mm). Ensure the Crossbar Sliding Plate is securely attached to the crossbar.